



## Installation of the Artillian Turf Feet™

1. Remove one of the cotter pins from the mounting pin of one of the factory stabilizer feet on your backhoe.
2. Pull the mounting pin out while holding onto the factory stabilizer foot. Set the foot aside.
3. Start the mounting pin into one of the mounting holes of one of the Artillian Turf Feet.
4. Orient the Turf Foot on the stabilizer leg so that the “Artillian” decal will be facing outward when installed.
5. Push the mounting pin through the holes on the stabilizer leg and through the other mounting hole on the Turf Foot until the pin is seated all the way in against the remaining cotter pin. **The mounting pin may be a little tight during installation but will wear in with use.**
6. Insert the hairpin cotter pin through the hole in the mounting pin.
7. Repeat on other side of tractor and enjoy!



## Street Pads

1. (Removal from Turf Foot) Remove the hairpin cotter pins from the two mounting pins of the Street Pad, which are visible from the top of the Turf Foot.
2. Lower the Street Pad down and out of the mounting holes in the Turf Foot.
3. Capture the two washers and replace both the washers and hairpin cotter pins back onto the mounting pins of the Street Pads for storage.
4. Installation is the reverse of the above. It may be helpful to use a small block of wood or another hand tool to help push the mounting pins of the Street Pad through the holes in the Turf Foot.